



Required Items for Installation:

- ADC-V520 camera and power adapter (included)
- Broadband (Cable, DSL, or Fiber Optic) Internet connection with router
- Personal computer or web-enabled tablet
- Login/password for the customer's Alarm.com account
- A router with a Wi-Fi Protected Setup (WPS)  button or an Ethernet cable
- If the router does not have a WPS button, and the camera will be connected to a wireless network, you will need the case-sensitive SSID (wireless network name) and the network WEP or WPA key (if encryption is enabled at the router)



Install the Camera(s):



*If you experience difficulties with the camera setup process, hold down the Reset button with a paper clip for 15 seconds to reset the camera.

1. Connect the camera's AC adaptor and plug it into a non-switched outlet.
2. Press and hold the camera's WPS button for 3 seconds and then press the corresponding WPS button on the router. *Note: If the router does not have a WPS button or if you have trouble connecting, use a standard Ethernet cable to connect the camera to the network router.**
3. From a computer on the same network as the camera, log into the customer's account at www.alarm.com/login.
4. Type **www.alarm.com/addcamera** into the web browser address bar and follow the on-screen instructions to add the camera to the Alarm.com account.

*You can configure the camera's wireless settings when setup is complete. Click on the "Configure wireless network settings for this camera" link and follow the on-screen instructions.

Questions? Contact Alarm.com Dealer Support at
1.866.834.0470 or Support@alarm.com.

EZ.INSTALL[™]